

SPINNAKER EQUIPMENT

To use the spinnaker with good control you need equipment which is adapted to the type of boat and to its use. Thanks to their experience and knowledge, sparcraft can supply you with the spinnaker equipment that matches your requirement (see also spinnaker pole chapter page 49).



Mast stowage systems



Stainless steel strap


Sparcraft can supply various systems to stow away the spi pole horizontally or vertically (with adjustment of the height).

■ **Mast stowage systems :**

This allows you to put away the spar vertically on the front side of the mast, to free the deck, and to adjust the height of the spi pole in position. The locking is done, according to the section, with the jaw on a large stainless steel strap and wedge.

■ **Spi pole track :**

- Track for car bearing 32 x 5.5 to rivet : for boats smaller than 40' ;
- Track for car bearing 32 x 5.5 to screw: for boats from 40' to 50" ;
- F40 ball track : For boats longer than 50' ;
- Track stops available with or without sheave for tracks 32 x 5.5 ;
- Track stops with sheaves available for F40 ball tracks.




■ **Sliders / toggles / car bearings / spi track blocks :**

Available per sets, or separate parts, please ask us for advice.



■ **Horizontal stowage system (on the deck):** Stainless steel pole stowage allowing you quickly put away the spi pole on the deck (stainless steel ø8).



Spi eyes

■ These are used to put the spi pole in position on the front side of the mast. Various types are available: fixed spi eyes, or on a track for adjustment, standard or reinforced, simple or with a piston.



Spi eye for adjustment with piston



Spi eye

Spi pole ends

■ There are many sparcraft spi pole ends available: piston, automatic jaw, jockey pole, composite or aluminum.

