

SPREADER SECTIONS DETERMINATION**DÉTERMINATION DE LA SECTION DE BARRE DE FLÈCHE**

Mast section Section Mât	Spreader 1 1^{er} étage	Spreader 2 2^{ème} étage	Spreader 3 3^{ème} étage
S35	BF2	BF2	
S50	BF2	BF2	
S67	BF2	BF2	
S80	BF2	BF2	
S137	BF3	BF3	
S180	BF3	BF3	
S260	BF3	BF3	
S265E	BF3	BF3	
S330	BF3	BF3	
S365E	BF3	BF3	
S400	BF4	BF4/BF3	BF3
S510	BF4	BF4/BF3	BF3
S560E	BF4/BF3	BF4/BF3	
S622	BF4	BF4	BF3
S760E	BF4	BF4	BF4
S830	BF5	BF5/BF4	BF4
S980E	BF5	BF4	BF4
S1060	BF5	BF5	BF4
S1170	BF5	BF5/BF4	BF4
S1210	BF5	BF5	BF4
S1395	BF5	BF5	BF5
S1420E	BF5	BF5	BF5
S1540	BF5	BF5	BF5
S1630	BF5	BF5	BF5
S1980E	BF5	BF5	BF5
S2100	BF5	BF5	BF5
S3410	BF6	BF6	BF5
S3800E	BF6	BF6	BF5
S4600	BF6	BF6	BF6
S7150E	Contact us / Nous consulter		
S7800			